

Lijst van horlogebatterijen / Liste des piles



01-01-19

Hoorapparaat Batterijen

Piles Auditieives

	Référence Referentie
386/301	301
357/303	303
	309
	315
	317
	319
	321
	329
	335
	337
	339
	341
344/350	344
	346
344/350	350
357/303	357
362/361	361
362/361	362
364/363	363
364/363	364
	365
	366
371/370	370
371/370	371
	373
377/376	376
377/376	377
	379
394/380	380
391/381	381
392/384	384
386/301	386
390/389	389
390/389	390
391/381	391
392/384	392
	393
394/380	394
395/399	395
397/396	396
397/396	397
395/399	399

Référence Referentie
CR 1025
CR 1216
CR 1220
BR 1225
CR 1612
CR 1616
CR 1620
CR 1625
CR 1632
CR 2012
CR 2016
BR 2020
CR 2025
CR 2032
CR 2320
BR 2325
BR 2330
CR 2354
CR 2354 N
CR 2412
CR 2430
CR 2450
CR 2477
CR 2477 N
CR 3032
LR1 / E90
LR03 / AAA
LR6 / AA
LR9 / EPX625G
LR14 / C
LR20 / D
6LR61 (9V)
LR43 / 186
LR44 / A76
LR54
E11A (6V)
A544 (6V)
E23A (12 V)
A27 (12 V)
2CR5
LR50 / PC1A
2L76

Référence Referentie
10 (230)
13
312
675